

# Updated Steps:

## Perform the following steps between 17 and 18

Locate the (2) Poly bumpstops and (2) clip nuts. Working on the driver side, install the clip nut in the front control arm bumpstop pad. Install the new poly bump stop into the clip nut and tighten until the poly starts to mushroom out and stop. Repeat on passenger side.

