

TUFF COUNTRY SUSPENSION

PART #FTBM
TRACKING BRACKET INSTRUCTIONS

PARTS LIST:

- (1) Tracking Bracket
- (1) 9/16" x 4" Bolt
- (1) 1/2 x 6 1/2" Bolt
- (1) 9/16" Lock Nut
- (1) 1/2" Lock Nut
- (2) 9/16" Flat Washer
- (2) 1/2" Flat Washer

Read and understand instructions prior to installation of tracking bracket. And follow each step in order.

Installation Instructions

1. Raise front of vehicle and support with jack stands on from behind strut arm brackets
2. Place jack on front axle and retain pressure on axle so it can be moved from side to side.
3. Un-bolt OEM tracking arm at frame and let it lay out of way.
4. Place the new bracket over the factory bracket and bolt into place using the 9/16" x 4" where the original tracking bracket was located.
5. Drill the factory bracket using the new bracket as a guide in both places on the sides.
6. Locate and install tracking arm in its new location with original bolt.
7. Be sure all bolts are tight and lower vehicle.

Note: Due to different lengths of stock ford tracking arm brackets, the upper hole of the new bracket may interfere with the upper bolt installed at the factory. In this case enlarge the hole so the bracket fits flush to the factory bracket and drill a new hole in between the two holes, then bolt together.

Recommendations for best handling:

Install new urethane tracking arm bushings, C-bushings and radius arm bushings.