

INSTALATION INSTRUCTIONS
RUNNING BOARD COMPOSITE

Part's List:

1 Set of Running Boards Composite

Required Tools:

x1 Ratchet

x 1/2" Socket

Steps:

1. Install the brackets (sold separately) on the vehicle.
2. Insert the Square Head bolts (Included on the brackets kit) on the rails as shown on illustration.
3. Locate the obrounds on the bracket and place the bolts inside.
4. Place Flat Wahser, Lock Washer and Hex nut (included on the bracket kit).
5. Align and adjust the running board.
6. Tighten all the Hex Nuts.

