



Description: LED Tail Lights

Part Number: 311213, 311214, 311215, 311216, 311217, 311218, 311219, 311220

Application: 2014 and up Chevy Silverado/ GMC Sierra 1500 2015 Chevy Silverado/GMC Sierra 2500, 3500

Tools Needed
Torx bit set
3/8 Ratchet



Start by opening your tailgate.



Remove the 2 Torx screw holding
the taillight in.



Remove your stock sockets from
the back of the light.



Once you have removed the sockets
from the housing. Remove the bulbs
from the sockets. Leave the reverse
bulb alone.



Next plug the connectors into your
stock socket. Be sure to line
the black wire up on the same
side on both the socket
and connector.

Twist your connectors into the new
housing and reinstall the
taillight back on the vehicle the
same way you removed it.



Test all functions of the light
before driving on public
highways.

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.