



Disconnect the plug from the circuit board on the passenger side located above the tail pipe.



Remove the two Phillips head screws that hold the taillight in place. Pull the taillights straight out.



Install the resistor boxes in a location out of the way of the taillight housing.



Connect the resistors to the wire harness. Make sure they are plugged in securely.



Reinstall the two screws to secure the fit.



Connect the new wire harness to the circuit board underneath the vehicle. Make sure all functions are working properly before driving.



Follow all this step for driverside. Some Tahoes have two lefted sided plugs. Please used the supplied wire harness for those vehicles.



Please make sure the wires match black to black and green to green. If the wires do not match simply unplug and twist around.

Technical Support :  
**1 - (888) - 360 - 3696**  
techsupport@anzousa.com