



Completely read all the instructions before installation
Improper installation will void warranty!

Step 1



Tools needed:
Torx Wrench
7mm Socket
Trim Pin Remover

Step 2



Remove the ten torx screws
located on the top of the grille

Step 3



Remove the three torx screws
from the side of the wheel well

Step 4



Remove the 7mm bolt from the
upper side of the wheel well

Step 5



Unplug the power sources
from the fog lights

Step 6



Remove the grille by removing
the ten torx screws and four
push pins located at the bottom
of the grille

Step 7



Remove the two 7mm bolts
from the top of the headlight
housing

Step 8



Remove the headlights by
unplugging the power source

Step 9



Remove the Anzo headlights from
its box

Step 10

Step 11



Install the Anzo headlights by reversing the steps 2 to 8



Test all functions before operating the vehicle

AnzoUSA™ products are covered, by a limited one (1) year warranty, to be free of manufacturer's defects. However, certain AnzoUSA™ product categories have warranty policies which differ from this standard, please contact your representative for detailed category information. Damage due to improper installation or road hazards is not covered. Seller and manufacturers' only obligations shall be to replace the product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising out of the use of or the inability to use the product. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.

© 2008 AnzoUSA™. All rights reserved.