



INSTALLATION INSTRUCTIONS

2014-2017 POLARIS® RZR TURBO® REFLECT A-PILLAR MOUNT



PRODUCT INCLUDES:

(1) Mount #41648

* LIGHTS SOLD SEPARATELY

***THIS MOUNT FITS THE FOLLOWING LIGHTS:**

(2) REFLECT & (2) D-SERIES PRO / (2) D-SS PRO / (2) SR-M/Q PRO / (2) IGNITE

IMPORTANT

THANK YOU FOR PURCHASING RIGID PRODUCTS FOR YOUR VEHICLE.

Please read through all of these Instructions and tips before proceeding with the installation.

We do our best to provide a simple installation process for all applications however a professional installation is always recommended.

**Always disconnect any power sources connected to your vehicle
before servicing fuses or electrical systems.**

STEP 1

Begin by prepping the Reflect mirror assemblies. Utilizing a 7/32" hex bit, remove the pre-installed mounting clamp bases from the mirrors.

See Figure 1

FIGURE 1



STEP 2

The Reflect Flat Mount Base Kit includes all necessary hardware for installation, including a longer flat head socket cap screw to attach the new puck. Retain the unique washer for re-installation.

See Figure 2

FIGURE 2



STEP 3

Install new base similar to as shown in Figure 3 (clocking may be different for this application). This bolt may have to be loosened to allow rotation and clocking of the base, and angle ring to allow the desired angles side to side, and relative to the vehicle for optimal appearance.

See Figure 3

FIGURE 3



STEP 4

Install the mirrors onto the A-Pillar mounts as shown in Figure 4.

See Figure 4

FIGURE 4



STEP 5

Remove and set aside (2) 15mm bolts from roll cage front attachment point as shown in Figure 5. These could be set aside for future use, but they will be replaced with longer bolts for these mounts.

See Figure 5

FIGURE 5



STEP 6

Install RIGID mount to roll cage using the provided 10mm x 50mm bolts as shown in Figure 6. If using a windshield, it may be necessary to use the provided spacers to offset the bracket from the roll cage.

See Figure 6

FIGURE 6



STEP 7

Install D-Series PRO, D-SS PRO, SR-M/Q PRO, or Ignite onto front tab of mount according to the instructions provided with the light. See Figure 7.

See Figure 7

FIGURE 7



STEP 8

Wire the Reflects and front mounts according to the instructions provided with each light. Your installation is now complete!

**Wiring: Wire your lights according to the instructions included with the light.
Take care to avoid any heat sources and sharp or abrasive surfaces.**

**Your installation is now complete.
Welcome to the Rigid Nation!**

WARRANTY INFORMATION

For warranty information, visit www.rigidindustries.com/about/warranty

779 N Colorado St, Gilbert, AZ 85233 • 855-760-5337
www.rigidindustries.com

REFLECT, RIGID, and Rigid Industries are registered and/or common law marks owned by JST Performance, LLC, a Delaware limited liability company d/b/a Rigid Industries.

11-12825-A