


Installation Instructions

3, 4, & 6000 Series Step Pad Part Number SP400

Parts List

| Qty. | Part # | Description |
|------|--------|---------------|
| 1 | SP400 | Step Pad |
| 2 | | Plastic Nails |

Step-1 Remove the existing step pad, using a punch and hammer to drive the step pad plastic nails downward into the tube.



Step-2 Working from the back of the step pad position a flat blade screw driver underneath the step pad and pry upward to remove from the tube.

Note: Use caution to protect the finish while removing the pad.

Step-3 Position the replacement step pad on the tube and align the step pad pins with the attachment holes. Press down on the step pad to snap into the holes and install the plastic nails to secure.

